





FM7 (FM7.mkd)



Port Setting

Encoder	PORT A
Slider	PORT A
PAD (1-8)	PORT B
PAD (9-16)	PORT A
Pedal	PORT A
Joystick-X	PORT A
Joystick-Y	PORT A
Joystick SW	PORT A
Keyboard	PORT A
Message	PORT A