


# STANDARD STRAT® HH, R/W, 0134800

## SWITCH & CONTROL FUNCTION



3 WAY SWITCH POSITION			
1	2	3	POSITION
MV T2	MV T1 / MV T2	MV T1	CONTROL
			← NECK PICKUP (A)
			← BRIDGE PICKUP (B)

MV = MASTER VOLUME CONTROL  
T1 & T2 = TONE CONTROL

INDICATES POSITION OF 3 WAY SWITCH

	PICKUP IS ON
	PICKUP IS OFF
<i>A</i>	PICKUP (NECK)
<i>B</i>	PICKUP (BRIDGE)