

J5 TELECASTER® , 013-9000/306

REF.#	P/N	DESCRIPTION
1	0064304000	Neck, John 5 Telecaster®, RW
2	0056260000	Tuning Key, RH (E, B, G, D,)
	0058815000	Washer
	0058820000	Bushing
3	0056261000	Tuning Key, LH (E, B, G, D,)
	0058815000	Washer
	0058820000	Bushing
4	0083675000	Bone Nut
5	0038467000	Truss Rod Adjusting Wrench
6	0064303506	Body, John 5 Telecaster®
7	0033024000	Neck Mounting Plate
	0015636000	Mounting Screw
8	0012344000	Strap Button
	0015610000	Mounting Screw
	0019056000	Felt Washer, Black
9	0064305000	Pickguard, John 5 Tele, Chrome
	0015578000	Mounting Screw
10	0058128000	Pickup, Twisted Tele Neck
	0050166000	Mounting Screw
	0039410000	Mounting Tube
11	0065279000	Pickup, Enforcer, HB Bridge
	0050166000	Mounting Screw
	0050167000	Mounting Spring
12	0019064000	Control 250K Audio Metal, Bridge Volume
	0016352000	Mounting Nut
	0016436000	Lock Washer
13	0019064000	Control 250K Audio Metal, Neck Volume
	0016352000	Mounting Nut
	0016436000	Lock Washer
14	0063865000	Control Plate John 5 Telecaster®
	0015578000	Mounting Screw
15	0058386000	Knob, Volume 1 & 2
	0028897001	Mounting Screw
16	3511045338	Switch, Toggle 3 Way, Chrome
17	0067920000	Plate, Toggle Switch John 5 Tele
	0015578000	Mounting Screw
18	0021956000	Output Jack
	0016436000	Lock Washer
	0016352000	Mounting Hex Nut
	0050100000	Jack Ferrule, Chrome
	0031153000	Flat Washer
19	0063560000	Bridge Assembly w/o PU
	0064306000	Mounting Screw
	0050919000	Adjusting Wrench
20	0021429000	Ferrule, String Retainer