













J5 TELECASTER® , 013-9000/306
SWITCH & CONTROL FUNCTION



3 WAY SW POSITIONS			
			POSITION
			← NECK (A)
			← BRIDGE (B)
NECK ONLY	NECK & BRIDGE PARALLEL CONNECTION	BRIDGE ONLY	CONNECTION

	PICKUP IS ON
	PICKUP IS OFF
<i>A</i>	PICKUP (NECK)
<i>B</i>	PICKUP (BRIDGE)